



Active Thermal Management

*The trusted name in thermal protection*

### **Instructions for installation of the System 1 adjustable thermal switch**

The adjustable thermostat can be set to turn the fan on between 80 and 130 degrees. To install, simply plug the thermal switch accessory into an always-live source of 120 Vac power, and plug the System 1's fan into the female end of the thermal switch's power cord. Place the thermal switch assembly where it can sense the heat generated by the equipment in the enclosure. Set the adjustable switch's knob to the desired turn-on temperature. There is a fixed 8-10 degree temperature differential; the fan will turn off 8 to 10 degrees below the temperature at which it turns on.

A hair dryer can be used to test the thermal switch for proper operation. The face plate of the switch is the temperature-sensitive element.

25570 Rye Canyon Rd.  
(661) 294-7999 voice  
[techinfo@activethermal.com](mailto:techinfo@activethermal.com)

Valencia, California 91355  
(661) 294-1115 fax  
[www.activethermal.com](http://www.activethermal.com)